







Notes

- Layout and dimensions are indicative and are subject to change after detailed design.
- 2. All dimensions are in metres.



Figure 5.6 Indicative Substation Compound Elevations

Tangy IV Wind Farm EIA Report